The nose

Our vision

The procedure

Why Open?

The future

FLUID DYNAMICS OF THE NASAL CAVITY: HOW TO, WHAT FOR.


Maurizio Quadrio

Politecnico di Milano Dept. of Aerospace Sciences and Technologies The nose

Our vision

The procedure

Why Open?



CREDITS

The nose

Our vision

The procedure

Why Open?

- Giovanni Felisati (Polo Osp. s.Paolo Milano & UniMI)
- Carlotta Pipolo (Polo Osp. s.Paolo Milano & UniMI)
- Francesco Messina (Polo Osp. s.Paolo Milano)
- Samuele Zampini (DAST PoliMI)
- Stefano Corti (DAST PoliMI, STR)
- Chiara Pesci (DAST PoliMI)

OUTLINE

The nose

Our *vision*

The procedure

Why Open?

- 1 THE NOSE
- 2 OUR vision
- 3 THE PROCEDURE
- 4 WHY OPEN?
- 5 THE FUTURE

FUNCTIONS OF THE HUMAN NOSE

The nose

Why Open?

The future

First (upper) part of respiratory airways

- Air filtering
- Air humidification
- Air heating
- Olfactive perception (+ taste)

INTERNAL STRUCTURE

The nose


Our vision

The procedure

Why Open?

The future

Nose and Nasal Cavities




SINUSES AND TURBINATES

The nose

Our vision

The procedure

Why Open?




A 3D VIEW

The nose

Our vision

The procedure

Why Open?




CORONAL SECTION: TURBINATES AND MEATA

The nose

The

Why Open?



- A: Olfactory region

- F: Inferior meatus


SIGNIFICANT LONGITUDINAL VARIATIONS

The nose

Our vision

The procedure

Why Open?



HOW TO STUDY THE NASAL CAVITY

The nose

Our vision

The procedure

Why Open?

- In-vivo approach: difficult, not useful
- In-vitro approach: rarely used
- First meaningful CFD study in 2004 (Zhao, Chem. Senses)

CFD: STATE OF THE ART

The nose

Our vision

The procedure

Why Open?

- Long times (weeks/months) for producing a mesh
- Questionable (but never questioned!) modellistic approaches
- RANS (or laminar)
- Results cannot be verified


MODELLING LIMITATIONS

The nose

Our vicion

The procedure

Why Open?



OUTLINE

The nose

Our vision

The procedure

Why Open?

- 1 THE NOSE
- 2 OUR vision
- 3 THE PROCEDURE
- 4 WHY OPEN?
- 5 THE FUTURE

THE PROBLEM

The nose

Our vision

The procedure

Why Open?

The future

In 2009 Regione Lombardia has spent:

- Septoplastic: 5600 procedures, 8.6M€
- Turbinates surgery: 3000 procedures, 4.3M€
- FESS: 5700 procedures, 11.6M€

FESS

The nose

Our vision

procedure

Why Open?

The future

Nowadays functional endoscopic sinus surgery (FESS) is the gold standard for chronic NBD treatment. The operation generally involves inferior/middle turbinoplasty and uncinate and ethmoid excision, sometimes followed by opening of the maxillary, sphenoid and frontal sinuses. A correction of a nasal septal deviation can also be necessary.

. . .

However, we are currently unable to assess the relevance of every single anatomic anomaly and its surgical modification on the overall nasal flow quality and nasal obstruction.

Quadrio et al, 2013? 2014?



OUTLINE

The nose

ur vision

The procedure

2 OUR vision

Why Open?
The future

3 THE PROCEDURE

4 WHY OPEN?

5 THE FUTURE

THE PROCEDURE

The nose

Our *visior*

The procedure

Why Open?

- Patient-specific procedure
- CFD results from a CT scan
- Support to surgery planning (virtual surgery)
- Reliable results
- Robust and feasible procedure (time and cost)
- Goal: reduce / optimize surgery

THE TOOLCHAIN

The nose

Our vision

The procedure

Why Open?

- Analysis of CT scan (3DSlicer)
- 2 STL from CT scan (3DSlicer)
- 3 Volume mesh (OpenFOAM snappyHexMesh)
- CFD (OpenFOAM)


1/4 ANALYSIS OF THE CT SCAN

IMPORTANT SEPTAL DEVIATION

The nose

The procedure

Why Open?




1/4 ANALYSIS OF THE CT SCAN (2)

NEARLY-COMPLETE OBSTRUCTION

The nose

The procedure

Why Open?



2/4 STL FROM CT SCAN


WRONG HU THRESHOLD

The nose

Our *vision*

The procedure

Why Open?




2/4 STL FROM CT SCAN (2)

CORRECT HU THRESHOLD

The nose

The procedure

Why Open?




3/4 VOLUME MESH

CASTELLATED MESH

The nose

The procedure

Why Open?




3/4 VOLUME MESH (2) CASTELLATED MESH

The nose

The procedure


Why Open?



The nose

The procedure

Why Open?




3/4 VOLUME MESH (4) CASTELLATED MESH

The nose

Our *vision*

The procedure

Why Open?




3/4 VOLUME MESH (5) ADDING LAYERS

The nose

The procedure

Why Open?




4/4 CFD STEADY INSPIRATION, LAMINAR

The nose

The procedure

Why Open?



OUTLINE

The nose

Our *vision*

The procedure

Why Open?

- 1 THE NOSE
- 2 OUR vision
- 3 THE PROCEDURE
- 4 WHY OPEN?
- 5 THE FUTURE

THE ROLE OF OPENSOURCE AND OPENFOAM

The nose

Our *vision*

The procedure

Why Open?

- Freedom
- Reliability
- Flexibility

OUTLINE

The nose

Our *vision*

The procedure

Why Open?

- 1 THE NOSE
- 2 OUR vision
- 3 THE PROCEDURE
- 4 WHY OPEN?
- 5 THE FUTURE

NEXT STEPS

The nose

Our vision

The procedure

Why Open?

- Virtual surgery
- 3D-PIV lab experiment for validation (grant from Ministry of Health)
- LES
- Trial before large scale deployment

VIRTUAL SURGERY

REMOVING SEPTAL DEVIATION / TURBINATE REDUCTION

The nose

Our *vision*

The procedure

Why Open?

